









After printing, you should re-measure the reference dimension shown below. It has to be exactly 5 cm long. If the dimension is not correct, please check your printer settings – A4 landscape format, no margins, no automatic page adaption, printing size 10 % - and print again. mm = Millimetres, cm = Centimetres

Reference dimension, exactly 5 cm long